

Garmin Venture Cx Setup Instructions

Table of Contents

Step 1: Set Units

Step 2: Set Track Settings

Step 3: Set Map Settings (Optional)

Step 1: Set Units

- 1) Use Page Key to set page to "Main Menu"



- 2) Use Joystick to select "Setup"



- 3) Use Joystick to select "Units".
Set the Distance/Speed to "Yards".



Step 2: Set Track Settings

- 1) Use Page Key to set page to "Main Menu"




- 2) Use Joystick to select "Tracks".
Make sure that the "Track Log" is On.



- 3) Use the joystick to press "Clear",
then press "yes" to complete the track clearing process.



- 4) Use the Joystick to select "Setup"
 - a) Wrap When Full = Checked
 - b) Record Method: Distance
 - c) Interval: 10 yds




(Optional)

Step 3: Set Map Settings

- 1) Use Page Key to set page to "Map"



- 2) Press the Menu button. Then use the Joystick to select "Setup Map".



- 3) Set Orientation to "North Up".

